

ADDENDUM #2
RFB TDD 16-15
Exterior Siding, Soffit and Painting

Additional Requirements for RFB TDD 16-15:

1. Install a Tyvek vapor barrier before siding is installed and add to Scope of Work.
2. Paint any visible foundation material to match the bottom 1/3 Chestnut Brown siding.
3. Cut out a 4-inch continuous strip in the center of soffit for venation.
4. Set all existing rusted nails, caulk and paint around windows.
5. Replace all 1x6 corner trim boards with 2x6 treated corner boards.
6. Install vented soffit around building and a solid soffit in porch areas, all 10 inches wide in Cream color.
7. Cut out around existing panels and trim around panels, matching to correct paint color.
8. Insure all windows are flashed and caulked.
9. County Facility Maintenance responsible to remove and reinstall exterior vents, and remove Visitors Welcome Center above front entrance.
10. County Parks responsible to trim down building shrubbery to 1 foot above ground and remove oleander adjacent front entrance.